
Battery Installation/Removal

THE TLR-1®s/TLR-2®s MUST BE REMOVED FROM THE FIREARM BEFORE THE BATTERY COMPARTMENT CAN BE OPENED OR CLOSED.



4- Insert Tab into Slot to Close Door

